

PINTUCKING FOOT (narrow)

for 9 mm stitch width sewing machines ref: 202-094-209

The narrow pintucking foot is used with a 2mm twin needle to create rows of pintucks. Multiple grooves on the underside of the foot make it easy to stitch evenly spaced parallel rows. Corded pintucks can be created with cords less than 1.5mm in diameter.



♠ Caution

Make sure to press the Lockout key when replacing the foot or attaching a binder.

For models without the Lockout key, turn the power switch off when attaching and detaching the foot and binder.

Please refer to your machine's instruction manual for accessory attachment and removal information

Machine Settings:

Stitch pattern: straight stitch <

(center needle position)

Needle: twin needle Thread tension: 5 - 7

To Sew:

Sew on single layer of light weight fabrics such as georgette or de chine. When sewing parallel rows of pintucks, guide the pintuck previously sewn in the groove on the bottom side of the foot.

*Each groove is 2mm apart.

PIED NERVURE (étroit)

pour machines à coudre avec 9 mm de largeur de couture Réf: 202-094-209

Le pied nervure étroit est utilisé avec une aiguille jumelée de 2mm pour créer des rangées de nervures. Les multiples sillons sous le pied permettent de réaliser des rangées de nervures parallèles à intervalles réguliers. Des sillons en relief peuvent être créés avec des cordonnets de moins de 1,5mm de diamètre.

Attention

Appuyez sur le bouton de verrouillage lorsque vous remplacez le pied ou fixez un dispositif.

Pour les modèles de machines sans bouton de verrouillage, coupez le contact lorsque vous retirez ou fixez un accessoire.

Référez-vous au manuel d'instructions de votre machine à coudre pour toutes les informations concernant le fixation et le changement d'un accessoire.

Réglages de la machine:

Motif du point: point droit

(position de l'aiguille au centre)

Aiguille: aiguille jumelée Tension du fil: 5 - 7

Pour coudre:

Cousez sur une épaisseur de tissu fin tel que crêpe Georgette ou crêpe de Chine. Lorsque vous cousez des rangées de nervures parallèles, guidez la nervure déjà cousue dans le sillon de la partie arrière du pied.

*Chaque sillon est séparé de 2mm